

IBT100 FAQ's



How do I use the USB connection instead of RS232?

The communication settings for the IBT100 must be changed to use the USB port.

- 1) Press **Menu**
 - a. Scroll to **Communication** and press **Enter**
 - i. Scroll to **Port** and press **Enter**
 1. Change to **USB** and press **Enter**
 - a. Press **ESC** to exit menu
- 2) Open software, select USB as Communication Port, and click Connect.